



Altronix[®]

Plug-In Transformers

Specification Chart (all transformers listed are 120VAC input):

Model #	Output	Amp	UL Listed	Approx. Ship Wt.
TP1220	12VAC/20VA	1.7	X	1 lb.
TP1620	16.5VAC/20VA	1.2	X	12.9 oz.
TP1640	16.5VAC/40VA	2.4	X	1.8 lbs.
TP1650	16.5VAC/50VA	3	X	1.95 lbs.
TP2420	24VAC/40VA	.8	X	1.2 lbs.
TP2440	24VAC/40VA	1.67	X	1.7 lbs.
TP2450	24VAC/50VA	2	X	1.9 lbs.



Installation Instructions:

1. Connect wires to plug-in transformer.
2. Plug in the transformer to an outlet and secure transformer with screw provided.

Note: Measure output voltage before connecting devices. This helps avoid potential damage.

WARNING: This installation should be made by qualified service personnel and should conform to all local codes and in accordance with the National Electrical Codes.

Altronix is not responsible for any typographical errors. Product specifications are subject to change without notice.