



H-UC232S

USB 1.1 Compliant
RS-232 Serial Interface
Bus Powered
Two Year Warranty

PACKAGE CONTENTS:

- ◆ USB Serial Converter
- ◆ Driver Installation Diskette
- ◆ Easy-to-follow User's Manual



USB Printer Adapter: USB to Parallel Cable

The Hawking H-UC232S USB Serial Converter operates as a bridge between one USB port and a standard RS-232 Serial Port. You can easily connect the H-UC232S cable to your PC or Mac and connect it to any RS-232 device or DB-9P Male connector such as a PDA, Scanner, Printer, etc. Installation is easy with USB Plug and Play functionality. Connect your components together in no time at all!

SYSTEMS REQUIREMENTS:

- ◆ PC or Mac with available USB Port
- ◆ IBM Compatible Pentium-233 MHz or higher
- ◆ MS Windows 98SE, ME, 2000, & Mac 9.04 and 9.1
- ◆ 64 MB RAM or above

READY, NETWORK & GO!

It's easy to install, it's easy to use! Everyone can do it.

Step 1 - Connect the Cable

Connect the cable to your components and PC or MAC.

Step 2 - Install the Drivers

Power on your computer and insert the installation disk into your CD-ROM drive.

SPECIFICATIONS:

Operating Systems:

Windows 98SE/ME/2000
MAC 9.04 and 9.1

Standard:

USB specification Revision 1.1 compliant

Installation:

Plug and Play and Hot Plug Capable

Serial Interface:

RS-232

Data Transfer Rate:

500Kbps

Power Requirement:

None

HAWKING TECHNOLOGIES, INC

USA: 6A Faraday, Irvine, CA 92618

Europe: Rotterdam, The Netherlands

Sales: 888.662.8828, 949.580.0888

Fax: 949.580.0880

Email: sales@hawkingtech.com

Email: techsupport@hawkingtech.com

ORDERING INFORMATION:

H-U2PS2 PS2 to USB Adapter

H-U225HD 2.5" HD to USB Adapter

H-UC232S Serial Port to USB Adapter