

*Specification Chart (all transformers listed are 120VAC or 220VAC input):*

Model #	Output	Amp	A	B	C	D	E	F	G	H	Approx. Ship Wt.
T28140D	28VAC/175VA	6.25	3.125"	3.75"	3"	1.625"	3.125"	2.55"	2.5"	3"	3.5 lbs.

**Installation Instructions:**


1. Mount Transformer in desired location/enclosure.
2. Plug in the AC (120VAC or 220VAC 50 / 60 Hz) to an outlet.

**Note:** It is important to measure output voltage before connecting devices. This helps avoid potential damage.

3. Connect devices to secondary terminals on the transformer.

**WARNING: This installation should be made by qualified service personnel and should conform to all local codes and in accordance with the National Electrical Codes.**

**Fig. 1**



Altronix is not responsible for any typographical errors. Product specifications are subject to change without notice.